

## **CHECK LIST FOR STARTING BOAT**

1. **Battery isolator switch on (under seat)**
2. **Fuel line connected to a full tank**
3. **Fuel tank air vent open**
4. **Fuel bulb on fuel line pumped AS HARD AS POSSIBLE**
5. **Oil level OK**
6. **Kill switch NOT activated**
7. **Gear in neutral**
8. **Engine trim down AS FAR AS IT WILL GO**
9. **Push throttle lever forward past the first level of resistance AND HOLD FORWARD**
10. **Push ignition key in and turn for a few seconds to start**
11. **Repeat several times until started**
12. **Release throttle lever slowly after engine has run for 10 seconds or so**

If engine still does not start then give it a rest for at least 5 minutes  
(it will be flooded) then repeat above from step 8.

